Crane Scale Calibration Instruction

Press  display [2nd], press  again display [PASS-],

then display [00000], and press  to enter the password, press  to confirm.

If the password is wrong, back to weighing mode. If right, it can set up the unit, capacity, zero calibration and loading calibration.

Display [un kg], the unit is kg， and press  or  can change the unit to lb [un lb], press  to confirm.(option)

Display [FS 03], the max. capacity is 3t, and press  or  change the capacity range.

Display	Max.Cap	Division	Switchable division
FS 0.1	0.1t	0.05kg	0.02kg
FS 0.2	0.2t	0.1kg	0.05kg
FS 0.3	0.3t	0.1kg	0.05kg
FS 0.5	0.5t	0.2kg	0.1kg
FS 01	1t	0.5kg	0.2kg
FS 02	2t	1kg	0.5kg
FS 03	3t	1kg	0.5kg
FS 05	5t	2kg	1kg
FS 10	10t	5kg	2kg

Press  to confirm. Display [CALon] then press  to enter into weight calibration.

Display [LoAd0] is zero calibration, no loading, and the stable light on, press  to confirm. Display [0] Press , display [LoAd1] and load the weights, after 2 seconds, display [00000]. Press 

 to input the weight value, then press  to confirm the weight. After the weight is stable, and the stable light is on, long press  to confirm.

Display [End] ,press  to back to weighing mode.

Note：the pass word is 07650