LP7655 Crane Scale Calibration Instruction

When power on self test, Press HOLD UNIT and TARE ZERO to calibrate.

Display [CAL kg],the unit is kg，and press TARE ZERO can change the unit to lb, display [CAL lb], then press HOLD UNIT to confirm.

Display [FS 5]，the max. capacity is 300kg，and press TARE ZERO to change the capacity range.

Display	Max.Cap	Division	Calibration Loading Weight
FS 0	30.00kg	0.01kg	25kg
FS 1	60.00kg	0.02kg	50kg
FS 2	100.00kg	0.05kg	75kg
FS 3	150.00kg	0.05kg	100kg
FS 4	200.00kg	0.1kg	150kg
FS 5	300.00kg	0.1kg	200kg

Press HOLD UNIT to confirm.

Display [CALon] then press HOLD UNIT to enter into weight calibration，press  to exit.

Display [LoAd0] is zero calibration，no loading，press HOLD UNIT to confirm.
Display [LoAd1] is loading calibration，after the loading weight is stable, then press HOLD UNIT to confirm.

Display [End] ,then press HOLD UNIT to save weight calibration parameter and back to weighing mode; press  to exit.