LP7660B Calibration Instruction

When power on self test, Press HOLD UNIT and TARE ZERO to calibrate.

Display [dp 0], indicate no decimal point, and press TARE ZERO to change the decimal point, press HOLD UNIT to confirm.

Display [d 05], indicate the division, and press TARE ZERO to change the division, press HOLD UNIT to confirm.

Display [CAP]，indicate the max. capacity，press HOLD UNIT to set. Press  to left shift and press TARE ZERO to change the capacity range, press HOLD UNIT to confirm.

Display [CL 1]，indicate the number of load calibrate， press TARE ZERO to change the number, press HOLD UNIT to confirm.

Display [L 1]，indicate the first loading weight，press HOLD UNIT to set. Press  to left shift and press TARE ZERO to change the loading weight, press HOLD UNIT to confirm.

If you set 2 or 3 load calibrate , it will display [L 2]，indicate the second loading weight. then display [L 3]，indicate the third loading weight，.

Display [CALon] then press HOLD UNIT to enter into weight calibration，press  to exit.

Display [LoAd0] is zero calibration，no loading，press HOLD UNIT to confirm.

Display [LoAd1] is first loading calibration，after the loading weight is stable, then press HOLD UNIT to confirm.

If you set 2 or 3 load calibrate , it will display [LoAd2] is second loading calibration，then display [LoAd3] is third loading calibration, then press HOLD UNIT to confirm.

Display [End] ,then press HOLD UNIT to save weight calibration parameter and back to weighing mode; press  to exit.

Note : if you want lb, please press HOLD UNIT at weight mode, it will save lb unit.